

Descriere butoane functionale



: Porneste / opreste TV

SOURCE : afiseaza si selecteaza sursele video disponibile\

TV : selecteaza direct modul TV

HDMI : Selecteaza ricet modul HDMI

GUIDE : afiseaza ghidul electronic de programe (EPG)

VOL+/- : regleaza volumul



: acceseaza SM (smart hub) sau tineti apasat pentru accesarea celor mai recent utilizate aplicatii sau notificari



- aplicatii Smart Hub

TOOLS : Selectare rapida a celor mai frecvent utilizate functii

INFO : afiseaza informati pe ecranul TV

RETURN : revenire la meniul anterior

SLEEP : accesare timer sleep

EXIT : iesire din meniu

Butoane colorate  : taste directe pentru functii interactive

FAV.CH : lista canale favorite



: porneste / opreste functia 3D



: accesare Netflix



: accesare internet



: accesare "vudu"